
About this document

This document outlines the functions, specifications, applications, and operation of the various Meridian 1 line cards. This information is intended to be used as a guide when connecting the line cards to customer-provided station equipment.

References

See the Meridian 1 System planning and engineering guide for

- *Meridian 1 system engineering* (553-3001-151)
- *Spares planning* (553-3001-153)
- *Meridian 1 equipment identification* (553-3001-154)
- *Summary of transmission parameters* (553-2201-182)

See the Meridian 1 System installation and maintenance guide for

- *Meridian 1 system installation procedures* (553-3001-210)
- *Circuit card installation and testing* (553-3001-211)
- *Meridian 1 general maintenance information* (553-3001-500)
- *Meridian 1 fault clearing* (553-3001-510)
- *Meridian 1 hardware replacement* (553-3001-520)

See the X11 software guide for an overview of software architecture, procedures for software installation and management, and a detailed description of all X11 features and services. This information is contained in two documents:

- *X11 software management* (553-3001-300)
- *X11 features and services*

See the *X11 input/output guide* for a description of all administration and maintenance programs, and *X11 system messages guide* for information about system messages.